

## 11-140 Operating Instructions

Step 1: Fish the wire rope through each section of PVC pipe and then screw the sections of pipe together.



Step 2: Attach the shackle between the wire rope and the nylon web sling.



The assembly should look as shown below.



Step 3: Use the PVC pipe to lift the web sling over the beam you'd like to attach the lifeline to.





Step 4: Feed the PVC pipe back through the nylon web sling.





Step 5: Cinch the nylon web sling back up and over the beam.







Step 6: The nylon web sling is now ready to use.

