



Part No. 11-301-BP

Installation Instructions: 11-301-BP

1. Plug male end into main power cable for climbing hoist
2. Plug female end into the climbing hoist
3. Mount box on the underside of the False Car or platform using the two adjustable cord grips with rings
4. Use zip ties, if necessary, for additional support mounting below the deck
5. Box function should be checked each morning before the start of the day

Installation Instructions: 11-301-BPUNI

1. Install 9V rechargeable battery in signaling unit
2. Mount spring loaded wheel platform under CWT, False Car or platform so drive wheel is tightly resting against it using C-Clamps, Spot Welding or Rail Clips.
3. Mount signaling unit where light and audio signal can be seen and heard using zip ties.
4. Turn on and operate platform.
5. Box function should be checked each morning before the start of the day



Part No. 11-301-BPUNI



Part No. 11-301-BPUNI