


Rail Alignment Gauge, Dual Line 5/8"



Instructions

The Wurtec Rail Alignment Gauge (Dual Line) is perfect for aligning your rails to the target lines dropped using the Dual Line Ratchet Bracket.

1. Using the spring action clamp, clamp the Rail Alignment Gauge to the rail you wish to align. (Ensure a firm grip so the Rail Alignment Gauge does not fall.)
2. The see through gauge allows you to see if the piano wire is in the grooves of the alignment tool.
3. If the piano wire does not align with the grooves in the rail alignment tool, adjust the rail until both piano wires align with the rail alignment tool grooves.
4. When both piano wires are in the grooves you are now ready to set your rails.