









sprecher+schuh




OPTION
WAHL
OPZIONE
OPÇÃO
OPCIÓN





(A)						
(A)						
(B)						
						ø60, ø90
	30	40	50	40	50	
		30		40		60 / 90



Use the same size wire only
Utiliser uniquement du fil de même dimension
Nur Draht derselben Größe verwenden
utilizzare solo cavi della stessa dimensione
use somente fios do mesmo tamanho
usar sólo el mismo tamaño de cable



or
ou
oder
o



"R" option for ring connectors
option de "R" pour cosses à plage ronde
"R" Wahl für Ringkabelschuhe
opção "R" per capicorda ad anello
opção de "R" para conectores do anel
opción de "R" para los conectores del anillo



ATTENTION:

To prevent electrical shock, disconnect from power source before installing for service.